

# E3Z-LT/LR/LL

CSM\_E3Z-LT\_LR\_LL\_DS\_E\_6\_4

## Compact and Reliable Laser Photoelectric Sensor


- Safety and reliability with laser class 1 (JIS and IEC).
- Product lineup includes models with distance setting without influence of color.
- Maximum ambient operating temperature of 55°C and water-proof construction in E3Z class.



Be sure to read *Safety Precautions* on page 9.

## Applications

Detect the sides of large tiles.




Greatly Enhanced Beam Visibility  
for Easier Optical Axis Adjustment of Sensors

Count bottles.




Reliable Detection of  
Small Objects and  
Narrow Gaps with the Small Spot

Detect chip components on tape.



Long-distance Sensing  
at 300 mm (White Paper)

Detect protruding straws.














A Low Black/White Error for  
Applications with Mixed Colors

## Ordering Information

### Sensors (Refer to *Dimensions* on page 11.)

 Red light

Sensing method	Appearance	Connection method	Response time	Sensing distance	Model	
					NPN output	PNP output
Through-beam (Emitter + Receiver) *4		Pre-wired (2 m)*3	1 ms	 60 m	<b>E3Z-LT61 2M</b> Emitter E3Z-T61-L 2M Receiver E3Z-T61-D 2M	<b>E3Z-LT81 2M</b> Emitter E3Z-T81-L 2M Receiver E3Z-T81-D 2M
		Connector (M8, 4 pins)			<b>E3Z-LT66</b> Emitter E3Z-T66-L Receiver E3Z-T66-D	<b>E3Z-LT86</b> Emitter E3Z-T86-L Receiver E3Z-T86-D
Retro-reflective with MSR function		Pre-wired (2 m)*3		 15 m (300 mm) (Using E39-R1)	<b>E3Z-LR61 2M</b>	<b>E3Z-LR81 2M</b>
		Connector (M8, 4 pins)		 7 m (200 mm) (Using E39-R12)		
				 7 m (200 mm) (Using E39-R6)	<b>E3Z-LR66</b>	<b>E3Z-LR86</b>
Distance-settable (BGS Models)		Pre-wired (2 m)*3	0.5 ms	 20 to 40 mm (Min. distance set)	<b>E3Z-LL61 2M</b>	<b>E3Z-LL81 2M</b>
		Connector (M8, 4 pins)		 20 to 300 mm (Max. distance set)	<b>E3Z-LL66</b>	<b>E3Z-LL86</b>
		Pre-wired (2 m)*3		 25 to 40 mm (Min. distance set)	<b>E3Z-LL63 2M</b>	<b>E3Z-LL83 2M</b>
		Connector (M8, 4 pins)		 25 to 300 mm (Max. distance set)	<b>E3Z-LL68</b>	<b>E3Z-LL88</b>

\*1. The Reflector is sold separately. Select the Reflector model most suited to the application.

\*2. Values in parentheses indicate the minimum required distance between the Sensor and Reflector.

\*3. Pre-wired Models with a 0.5-m cable are also available for these products. When ordering, specify the cable length by adding "0.5M" to the end of the model number (e.g., E3Z-LT61 0.5M).

M12 Pre-wired Connector Models are also available. When ordering, add "M1J" to the end of the model number (e.g., E3Z-LT61-M1J). The cable is 0.3 m long.

Also, the following connection forms can be manufactured. Ask your OMRON representative for details.

- Pre-wired Models with 1-m or 5-m cables
- Pre-wired Connector Models with M8 4-pin connectors or M8 3-pin connectors.

\*4. Through-beam Sensors are normally sold in sets that include both the Emitter and Receiver.

Orders for individual Emitters and Receivers are accepted. (Modifications are required for some models. Ask your OMRON representative for details.)

### Accessories










**Slits** (A Slit is not provided with a Through-beam Sensor. Order a Slit separately if required.) (Refer to *Dimensions* on page 14.)

Slit width	Sensing distance	Minimum detectable object (typical)	Model	Contents
0.5 mm dia.	3 m	0.1 mm dia.	<b>E39-S65A</b>	One set (contains Slits for both the Emitter and Receiver)

**Reflectors** (A Reflector is required for Retro-reflective Sensors: A Reflector is not provided with the Sensor. Be sure to order a Reflector.)  
(Refer to *Dimensions* on page 14.)

Name	Sensing distance (typical)	Model	Remarks
Reflector	15 m (300 mm)	<b>E39-R1</b>	<ul style="list-style-type: none"> <li>• Retro-reflective models are not provided with Reflectors.</li> <li>• Separate the Sensor and the Reflector by at least the distance given in parentheses.</li> <li>• The MSR function is enabled.</li> </ul>
	7 m (200 mm)	<b>E39-R12</b>	
	7 m (200 mm)	<b>E39-R6</b>	

**Mounting Brackets** A Mounting Bracket is not provided with the Sensor. Order a Mounting Bracket separately if required.  
(Refer to *Dimensions* on E39-L/F39-L/E39-S/E39-R.)





Appearance	Model	Quantity	Remarks	Appearance	Model	Quantity	Remarks
	E39-L153	1	Mounting Brackets		E39-L98	1	Metal Protective Cover Bracket *
	E39-L104	1			E39-L150	1 set	(Sensor adjuster)
	E39-L43	1	Horizontal Mounting Bracket *		E39-L151	1 set	Easily mounted to the aluminum frame rails of conveyors and easily adjusted. For left to right adjustment
	E39-L142	1	Horizontal Protective Cover Bracket *				
	E39-L44	1	Rear Mounting Bracket		E39-L144	1	Compact Protective Cover Bracket (For E3Z only) *

Note: When using a Through-beam Sensor, order one Mounting Bracket for the Receiver and one for the Emitter

\* Cannot be used for Standard Connector models.

## Sensor I/O Connectors

(Models for Connectors and Pre-wired Connectors: A Connector is not provided with the Sensor. Be sure to order a Connector separately.)  
(Refer to *Dimensions* on XS3, XS2)

Size	Cable	Appearance	Cable type		Model
M8	Standard	<div>Straight *1</div> 	2 m	4-wire	XS3F-M421-402-A
			5 m		XS3F-M421-405-A
		<div>L-shaped *1 *2</div> 	2 m		XS3F-M422-402-A
			5 m		XS3F-M422-405-A
M12 (For -M1J models)		<div>Straight *1</div> 	2 m	3-wire	XS2F-D421-DC0-A
			5 m		XS2F-D421-GC0-A
		<div>L-shaped *1</div> 	2 m		XS2F-D422-DC0-A
			5 m		XS2F-D422-GC0-A

Note: When using a Through-beam Sensor, order one Mounting Bracket for the Receiver and one for the Emitter

\*1. The connector will not rotate after connecting.

\*2. The cable is fixed at an angle of 180° from the sensor emitter/receiver surface.

## Ratings and Specifications


Sensing method		Through-beam	Retro-reflective with MSR function	Distance-settable (BGS models)		
Response		Standard response			High-speed response	
Item	Model	NPN output	E3Z-LT61/-LT66	E3Z-LR61/-LR66	E3Z-LL61/-LL66	E3Z-LL63/-LL68
		PNP output	E3Z-LT81/-LT86	E3Z-LR81/-LR86	E3Z-LL81/-LL86	E3Z-LL83/-LL88
Sensing distance		60 m	0.3 to 15 m (when using E39-R1) 0.2 to 7 m (when using E39-R12) 0.2 to 7 m (when using E39-R6)	White paper (100 × 100 mm): 20 to 300 mm Black paper (100 × 100 mm): 20 to 160 mm	White paper (100 × 100 mm): 25 to 300 mm Black paper (100 × 100 mm): 25 to 100 mm	
Set distance range		---			White paper (100 × 100 mm): 40 to 300 mm Black paper (100 × 100 mm): 40 to 160 mm	White paper (100 × 100 mm): 40 to 300 mm Black paper (100 × 100 mm): 40 to 100 mm
Spot diameter (typical)		5-mm dia. at 3 m			0.5-mm dia. at 300 mm	
Standard sensing object		Opaque: 12-mm dia. min.		Opaque: 75-mm dia. min.		---
Minimum detectable object (typical)		6-mm-dia. opaque object at 3 m			0.2-mm-dia. stainless-steel pin gauge at 300 mm	
Differential travel		---			5% max. of set distance	
Black/white error		---			5% at 160 mm	5% at 100 mm
Directional angle		Receiver: 3 to 15°		---		
Light source (wavelength)		Red LD (655 nm), JIS Class 1, IEC Class 1, FDA Class II				
Power supply voltage		12 to 24 VDC±10%, ripple (p-p): 10% max.				
Current consumption		35 mA (Emitter 15 mA, Receiver 20 mA)		30 mA max.		
Control output		Load power supply voltage: 26.4 VDC max., Load current: 100 mA max., Open collector output				
Residual output voltage		Load current of less than 10 mA: 1 V max. Load current of 10 to 100 mA: 2 V max.				
Output mode switching		Switch to change between light-ON and dark-ON				
Protection circuits		Reversed power supply polarity protection, Output short-circuit protection, and Reversed output polarity protection		Reversed power supply polarity protection, Output short-circuit protection, Mutual interference prevention, and Reversed output polarity protection		
Response time		Operate or reset: 1 ms max.				Operate or reset: 0.5 ms max.
Sensitivity adjustment		One-turn adjuster			Five-turn endless adjuster	
Ambient illumination (Receiver side)		Incandescent lamp: 3,000 lx max. Sunlight: 10,000 lx max.				
Ambient temperature range		Operating: -10 to 55°C, Storage: -25 to 70°C (with no icing or condensation)				
Ambient humidity range		Operating: 35% to 85%, Storage: 35% to 95% (with no icing or condensation)				
Insulation resistance		20 MΩ min. at 500 VDC				
Dielectric strength		1,000 VAC, 50/60 Hz for 1 min				
Vibration resistance		Destruction: 10 to 55 Hz, 1.5-mm double amplitude for 2 hours each in X, Y, and Z directions				
Shock resistance		Destruction: 500 m/s² 3 times each in X, Y, and Z directions				
Degree of protection		IP67 (IEC 60529)				
Connection method		Pre-wired cable (standard length: 2 m): Standard M8 Connector:		E3Z-L□□1/-L□□3 E3Z-L□□6/-L□□8		
Indicator		Operation indicator (orange) Stability indicator (green) Emitter for Through-beam Models has power indicator (orange) only.				
Weight (packed state)	Pre-wired cable (2 m)	Approx. 120 g		Approx. 65 g		
	Standard Connector	Approx. 30 g		Approx. 20 g		
Material	Case	PBT (polybutylene terephthalate)				
	Lens	Modified polyarylate resin		Methacrylic resin	Modified polyarylate resin	
Accessories		Instruction manual (Neither Reflectors nor Mounting Brackets are provided with any of the above models.)				

## Engineering Data (Typical)

### Parallel Operating Range


#### Through-beam Models

##### E3Z-LT□□




#### Through-beam Models

##### E3Z-LT□□ + E39-S65A



#### Retro-reflective Models


##### E3Z-LR□□



### Operating Range at a Set Distance of 300 mm

#### BGS Models


##### E3Z-LL□□



### Operating Range at a Set Distance of 40 mm

#### BGS Models


##### E3Z-LL□□



### Excess Gain vs. Set Distance


#### Through-beam Models

##### E3Z-LT□□



#### Retro-reflective Models


##### E3Z-LR□□




### Close Range Characteristics

#### BGS Models

##### E3Z-LL□1/LL□6



##### E3Z-LL□3/LL□8




## Sensing Distance vs. Sensing Object Material

### BGS Models


#### E3Z-LL□1-/LL□6

White Paper with a Set Distance of 40 mm




#### E3Z-LL□3-/LL□8

White Paper with a Set Distance of 40 mm




#### E3Z-LL□1-/LL□6

White Paper with a Set Distance of 300 mm



#### E3Z-LL□3-/LL□8


White Paper with a Set Distance of 100 mm



## Emission Spot Diameter vs. Distance


Through-beam and Retro-reflective Models (Same for All Models)

### E3Z-LT□□, E3Z-LR□□



BGS Models (Same for All Models)


### E3Z-LL□□




## Hysteresis vs. Distance

### BGS Models

#### E3Z-LL□1 (LL□6)




#### E3Z-LL□3 (LL□8)



## Inclination Characteristics (Vertical)

### BGS Models


#### E3Z-LL□□



## Inclination Characteristics (Horizontal)

### BGS Models

#### E3Z-LL□□



## I/O Circuit Diagrams

## NPN Output

Model	Operation mode	Timing charts	Operation selector	Output circuit
E3Z-LT61 * E3Z-LT66 * E3Z-LR61 E3Z-LR66	Light-ON		L side (LIGHT ON)	
	Dark-ON		D side (DARK ON)	
	<b>Through-beam Emitter</b> 			
E3Z-LL61 E3Z-LL66 E3Z-LL63 E3Z-LL68	Light-ON		L side (LIGHT ON)	
	Dark-ON		D side (DARK ON)	
	<b>Through-beam Emitter</b> 			

## PNP Output


Model	Operation mode	Timing charts	Operation selector	Output circuit
E3Z-LT81 * E3Z-LT86 * E3Z-LR81 E3Z-LR86	Light-ON		L side (LIGHT ON)	
	Dark-ON		D side (DARK ON)	
	<b>Through-beam Emitter</b> 			
E3Z-LL81 E3Z-LL86 E3Z-LL83 E3Z-LL88	Light-ON		L side (LIGHT ON)	
	Dark-ON		D side (DARK ON)	
	<b>Through-beam Emitter</b> 			

\* Models numbers for Through-beam Sensors (E3Z-LT□□) are for sets that include both the Emitter and Receiver.


The model number of the Emitter is expressed by adding "L" to the set model number (example: E3Z-LT61-L 2M), the model number of the Receiver, by adding "-D" (example: E3Z-LT61-D 2M). Refer to Ordering Information to confirm model numbers for Emitter and Receivers.

## Plugs (Sensor I/O Connectors)

### M8 4-pin Connectors



### M12 Connectors



## Nomenclature

### Sensors with Sensitivity Adjustment and Mode Selector Switch

#### Through-beam Models

E3Z-LT□□ (Receiver)


#### Retro-reflective Models

E3Z-LR□□

### Distance-settable Sensor

#### BGS Models

E3Z-LL□□





## Safety Precautions

Refer to *Warranty and Limitations of Liability*.

### WARNING

This product is not designed or rated for ensuring safety of persons. Do not use it for such purpose.



To ensure safe use of laser products, do not allow the laser beam to enter your eye. Direct exposure may adversely affect your eyesight.



### CAUTION

Do not connect an AC power supply to the Sensor. If AC power (100 VAC or more) is supplied to the Sensor, it may explode or burn.



### Precautions for Safe Use

Be sure to abide by the following precautions for the safe operation of the Sensor.

#### ● Operating Environment

Do not use the Sensor in locations with explosive or flammable gas.

#### ● Wiring

##### Power Supply Voltage and Output Load Power Supply Voltage

Make sure that the power supply to the Sensor is within the rated voltage range. If a voltage exceeding the rated voltage range is supplied to the Sensor, it may explode or burn.

##### Power Supply Voltage

The maximum power supply voltage is 26.4 VDC. Applying a voltage exceeding the rated range may damage the Sensor or cause burning.

##### Load

Do not use a load that exceeds the rated load.

##### Load Short-circuiting

Do not short-circuit the load, otherwise the Sensor may be damaged or it may burn.

##### Connection without Load

Do not connect the power supply to the Sensor with no load connected, otherwise the internal elements may explode or burn. Always connect a load when wiring.

### Precautions for Correct Use

Do not use the product in atmospheres or environments that exceed product ratings.

#### ● Laser Warning Labels

Be sure that the correct laser warning label (enclosed) is attached for the country of intended use of the equipment containing the Photoelectric Sensor. Refer to the user's manual for details.

#### ● Usage Environment

##### Water Resistance

The Sensor is rated IP67. Do not use it in water, in the rain, or outdoors.

##### Ambient Environment

Do not install the product in the following locations. Doing so may result in product failure or malfunction.

- Locations subject to excess dust and dirt
- Locations subject to direct sunlight
- Locations subject to corrosive gas
- Locations subject to organic solvents
- Locations subject to shock or vibration
- Locations subject to exposure to water, oil, or chemicals
- Locations subject to high humidity or condensation

#### ● Designing

##### Power Reset Time

The Sensor is ready to operate 100 ms after the Sensor is turned ON. If the load and Sensor are connected to independent power supplies respectively, be sure to turn ON the Sensor before supplying power to the load.

#### ● Wiring

##### Avoiding Malfunctions

If using the Sensor with an inverter or servomotor, always ground the FG (frame ground) and G (ground) terminals, otherwise the Sensor may malfunction.

#### ● Mounting

##### Mounting the Sensor


- If Sensors are mounted face-to-face, make sure that the optical axes are not in opposition to each other. Otherwise, mutual interference may result.
- Always install the Sensor carefully so that the aperture angle range of the Sensor will not cause it to be directly exposed to intensive light, such as sunlight, fluorescent light, or incandescent light.
- Do not strike the Photoelectric Sensor with a hammer or any other tool during the installation of the Sensor, or the Sensor will lose its water-resistive properties.
- Use M3 screws to mount the Sensor.
- When mounting the case, make sure that the tightening torque applied to each screw does not exceed 0.54 N·m.

##### Metal Connectors

- Always turn OFF the power supply to the Sensor before connecting or disconnecting the metal connector.
- Hold the connector cover to connect or disconnect it. If the XS3F is used, always tighten the connector cover by hand. Do not use pliers. If the tightening is insufficient, the degree of protection will not be maintained and the Sensor may become loose due to vibration. The appropriate tightening torque is 0.3 to 0.4 N·m. If other commercially available connectors are used, follow the recommended connector application conditions and recommended tightening torque specifications.


## Mounting Direction for Distance-settable Models

- Make sure that the sensing side of the Sensor is parallel with the surface of the sensing objects. Normally, do not incline the Sensor towards the sensing object.




If the sensing object has a glossy surface, however, incline the Sensor by 5° to 10° as shown in the illustration, provided that the Sensor is not influenced by background objects.


- If there is a mirror-like object below the Sensor, the Sensor may not operate stably. Therefore, incline the Sensor or separate the Sensor from the mirror-like object as shown below.




- Do not install the Sensor in the wrong direction. Refer to the following illustration.




Install the Sensor as shown in the following illustration if each sensing object greatly differs in color or material.



- The stability indicator may turn off in reaction to reflection from background objects. In such cases, incline the Sensor by 10° as shown in the illustration for more stable detection.



## Adjusting Distance-settable Models Indicator Operation



Note: If the stability indicator is lit, the detection/no detection status is stable within the rated ambient operating temperature (−10 to 55°C).

## Inspection and Maintenance


### Cleaning

Never use paint thinners or other organic solvents to clean the surface of the product.


## Dimensions

### Sensors


#### Through-beam \* Pre-wired Models E3Z-LT61 E3Z-LT81




#### M12 Pre-wired Connector (E3Z-LT□□-M1J)




#### Pre-wired Connector Models with M8 connectors (Inquire)




#### Pre-wired Connector Models with M8 3-pin connectors (Inquire)



\* The Emitter cable has two conductors and the Receiver cable has three conductors.



#### Through-beam \* Standard Connector Models E3Z-LT66 E3Z-LT86




\* Models numbers for Through-beam Sensors (E3Z-LT□□) are for sets that include both the Emitter and Receiver. The model number of the Emitter is expressed by adding "-L" to the set model number (example: E3Z-LT61-L 2M), the model number of the Receiver, by adding "-D" (example: E3Z-LT61-D 2M.) Refer to Ordering Information to confirm model numbers for Emitter and Receivers.

## Retro-reflective Models

### Pre-wired Models


E3Z-LR61

E3Z-LR81




Terminal No.	Specifications
1	+V
2	---
3	0 V
4	Output


### M12 Pre-wired Connector (E3Z-LR□□-M1J)



### Pre-wired Connector Models with M8 connectors (Inquire)



### Pre-wired Connector Models with M8 3-pin connectors (Inquire)




## Retro-reflective Models

### Standard Connector Models

E3Z-LR66

E3Z-LR86



Terminal No.	Specifications
1	+V
2	---
3	0 V
4	Output

## BGS Models


### Pre-wired Models

E3Z-LL61

E3Z-LL81


E3Z-LL63

E3Z-LL83




Terminal No.	Specifications
1	+V
2	---
3	0 V
4	Output


### M12 Pre-wired Connector (E3Z-LL□□-M1J)



### Pre-wired Connector Models with M8 connectors (Inquire)



### Pre-wired Connector Models with M8 3-pin connectors (Inquire)



## BGS Models

### Standard M8


### Connector Models

E3Z-LL66

E3Z-LL86

E3Z-LL68

E3Z-LL88




Terminal No.	Specifications
1	+V
2	---
3	0 V
4	Output

## Accessories (Order Separately)

### Slit E39-S65A




Material  
SUS301 stainless steel



### Reflector E39-R1




Materials  
Reflective surface: Acrylic  
Rear surface: ABS



### Reflector E39-R6



Materials  
Reflective surface: Acrylic  
Rear surface: ABS



### Reflector E39-R12



Materials  
Reflector: Polycarbonate (surface)  
Acrylic (interior)  
Frame: ABS

