

Installation Notes


NLP250CJ

Cover Accessory Kit

NLP250CJ will fit the NLP250 power supplies.

MATERIALS

- One (1) cover
- Four (4) M3x8 mm countersunk screws



Installation Instructions and Notes

1. Place the cover over the NLP250 as shown.
2. Align the cover to the U-bracket countersink holes.
3. Secure four (4) countersink screws provided with in kit as shown.
4. Overall dimensions: 7" (177.8 mm) x 4" (101.6 mm) x 1.6" (40.64 mm).
5. When using this enclosure, ensure that relevant safety standards (e.g., EN60950) are complied with, in respect to creepage and clearance distances, and distances through insulation.
6. All dimensions are in inches (mm)



ARTESYN™
An Advanced Energy Company

NLP250CJ Enclosure Installation Notes 20Dec2019