



**Applicator
Ram Spacer**

Application Tooling Specification Sheet




Order No. 63443-7200

FEATURES

- Separates upper and lower applicator tooling to prevent damage during shipping and storage.
- Inserts below adjustment cams on applicator ram.
- Can be inserted from front or rear side of ram.
- Can be used on both Mini-Mac and FineAdjust applicators

APPLICATION

- For shipping or storage, install ram spacer in applicator, as shown:



Warning:

The 63443-7200 Applicator Ram Spacer must be removed prior to installing the applicator into the press. Failure to do so may cause personal injury or damage to tooling.

<http://www.molex.com>