

# EM34x FULL-FEATURE REMOTE EVALUATION KIT QUICK-START GUIDE

#### **Unpacking the Contents**

ATTENTION: Observe precautions for handling electrostatic sensitive devices.

Remove components from their packaging:

Silicon Labs EM341 Full-Feature Remote Control (1) Ember® Debug Adapter (ISA3) (1) Telegesis USB Stick Packet Trace Port Cable (1) Packet Trace Header Connector (1)

DEI (Data Emulation Interface) Cable (1) Ethernet Cable (1) USB Cable (1) AA Batteries (2)

Software Serial Number

## QSG104

The EM34x Full-Feature Remote Evaluation kit provides the hardware and software necessary to demonstrate the functionality of the Silicon Labs Full Feature Remote Control. Access to software tools required to customize your own remote control application is also provided.

### **Kit Use Options**

The EM34xx Full Feature Remote Evaluation Kit offers you two ways of using and testing the Full-Feature remote:

- Full-Feature Remote Control Demonstration: An out-of-the-box demonstration of the remote's features, without further setup. See section 1, Running the Full Feature Remote Control Demonstration, for more information. Only the remote control, batteries, and USB stick are required for the demonstration.
- **Custom Application Development**: The ability to customize, compile, load, and run your own controller application, based on Silicon Labs reference designs. See section 2, Custom Application Development, for more information.

### 1 Running the Full Feature Remote Control Demonstration

The EM34x Full Feature Remote Evaluation Kit comes with the tools and software needed to test the remote's functionality out of the box. The Full Feature Remote comes pre-programmed with an example ZigBee Remote Control (ZRC) controller application. The USB stick contains an EM3588 chip preprogrammed with an example ZRC target application designed to show some of the remote's functionality. Demonstration software allows you to see packet transfer data from the controller to the target, button presses, and to hear voice recordings transmitted from the remote.

- 1. Download the RF4CE\_Demo\_Release.zip file from the <u>www.silabs.com/zrctraining</u> page.
- 2. Unzip the file to a location of your choice.
- 3. Install the USB stick driver from the RF4CE\_Demo\_Release\Windows\Driver\EM358CDCDriverInstaller folder created in step 2.
- 4. Plug the USB stick into a port on your computer.
- 5. Insert the batteries into the remote.
- 6. Launch the RF4CE\_Remote\_Demo application from the RF4CE\_Demo\_Release\Windows directory created in step 2.



## QSG104

RF4CE Remote Demo	1		? <mark>×</mark>
	Select Remote:		
SETUP TV STE INPUT MENU MENU MENU MENU	Universal_Electronics		
		Find Me	Pair
	COM Port:	Select a port 🔻	Refresh Ports
	Trace Data:	Save to File	Clear Trace
GUIDE			
VOICE O			
VOL LAST CH MUTE	Show Heartbeat Traces	Controller Heartbeat:	Target Heartbeat:
	Audio Data:	Hardware Codec Settings	
		Play Selected	Clear Audio
1 2 3			
4 5 6			
7 8 9			
LIST O ENTER			
(S)			
SILICON LABS			
UNIVERSAL ELECTRONICS. Franz han a visit of Provide			
	Play Audio Real Time Over Speakers		

- 7. In the Select Remote drop down list, select [Universal Electronics].
- 8. Select the USB stick's port. It will be assigned to a COM port.
- 9. Click [Pair] to initiate the pairing process.
- 10. On the remote, press and hold both the **[SET]** (small button on the upper left) and **[STB]** buttons. Release both buttons when the LED on the remote turns red. The LED will remain red while the remote is searching for a target device.
- 11. Once pairing is completed, the LED on the remote will turn off.
- 12. To verify the devices paired successfully, press a button on the remote and the corresponding button on the application remote graphic will turn green.



#### To demonstrate the remote locator functionality:

1. In the demonstration application, click **[Find Me]**. The remote will beep and the lights will flash for a period of time. There may be a delay between clicking **[Find Me]** in the application and the remote acknowledgement due to the polling time of the remote.

#### To demonstrate voice functionality:

- 1. In the demonstration application, make sure the Audio Data drop down is set to [Hardware Codec Settings].
- 2. On the remote, press and hold the **[VOICE]** button and speak. Release the **[VOICE]** button when you are done.

The remote wireless streams your voice to the USB device, where it is processed and stored as a .WAV file. All .WAV files on the USB device are listed under Audio Data.

- 3. To hear your recorded audio as it streamed to the target, in the application check [Play Audio Real Time Over Speakers].
- 4. To play a file, click the file in the list and click [Play Selected].
- 5. To clear all files from the USB device, click [Clear Audio].

### 2 Custom Application Development

You must be a registered user of the Silicon Labs Technical Support Portal and the EM34x Full-Feature Remote Evaluation Kit must be registered to obtain support and download the latest Silicon Labs development software and stacks. Go to <u>www.silabs.com/zrctraining</u> and follow the instructions to register your kit.

**Note:** Your software serial number will be in the form xxxx-xxxx-xxxx and can be found on Hardware Identification List label.

To download the development software, after you have completed registration and are logged into the Silicon Labs support page click the **Software Releases** tab, select **[latest EmberZNet Software]** from the drop-down menu, and sort by Release Date.

Download and install the latest version of the following tools. The release notes installed with the EmberZNet stack software include more detailed installation instructions and required version numbers.

- EmberZNet
- Ember Desktop
- ISA3 Utilities
- IAR Embedded Workbench for ARM (IAR-EWARM), installed through the IAR website

Licenses and support for IAR are provided separately and can be obtained from IAR Systems at <a href="http://www.iar.com">http://www.iar.com</a>.

An evaluation version of IAR can be downloaded directly at: <u>ftp://files.iar.com/pub/silabs/EWARM-7301.exe</u>

For more information on developing with the EM34x kits, refer to UG113, *EM34x Development Kit User's Guide*. See QSG105, *Getting Started with Silicon Labs Wireless Networking Software*, for information on how to configure and compile your own applications. See AN906, *RF4CE ZigBee Remote Control Firmware Guide*, for details on the reference designs. These and other useful documents are installed with the EmberZNet software. You can also use the Silicon Labs Technical Support Portal at <u>www.silabs.com/support</u>.



## **CONTACT INFORMATION**

#### Silicon Laboratories Inc.

400 West Cesar Chavez Austin, TX 78701 Tel: 1+(512) 416-8500 Fax: 1+(512) 416-9669 Toll Free: 1+(877) 444-3032

For additional information please visit the Silicon Labs Technical Support page: http://www.silabs.com/support

#### **Patent Notice**

Silicon Labs invests in research and development to help our customers differentiate in the market with innovative low-power, small size, analog-intensive mixed-signal solutions. Silicon Labs' extensive patent portfolio is a testament to our unique approach and world-class engineering team.

The information in this document is believed to be accurate in all respects at the time of publication but is subject to change without notice. Silicon Laboratories assumes no responsibility for errors and omissions, and disclaims responsibility for any consequences resulting from the use of information included herein. Additionally, Silicon Laboratories assumes no responsibility for the functioning of undescribed features or parameters. Silicon Laboratories reserves the right to make changes without further notice. Silicon Laboratories makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Silicon Laboratories assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. Silicon Laboratories products are not designed, intended, or authorized for use in applications intended to support or sustain life, or for any other application in which the failure of the Silicon Laboratories product could create a situation where personal injury or death may occur. Should Buyer purchase or use Silicon Laboratories products for any such unintended or unauthorized application, Buyer shall indemnify and hold Silicon Laboratories harmless against all claims and damages.

Silicon Laboratories, Silicon Labs, and Ember are registered trademarks of Silicon Laboratories Inc.

Other products or brandnames mentioned herein are trademarks or registered trademarks of their respective holders.

